



1. Place a block under one side of the Back as shown – The block should raise the Base off the floor by about 1”



2. Press down on the Arm with your knee as shown. Repeat for the other side. Lift Back up and off of the recliner



3. Lift the Back up and off of the recliner



4. Remove the two bolts shown from each Arm.



Make sure towel covers the bottom of the Back Post

5. Slide a Towel between the Arm and the Back Post of the Mechanism all the way to the bottom as shown.



6. Towels shown on both Back Posts. The Towels will protect the Inside Arm Leather from scratches.




For Powered Comfort Recliner: Unplug Chassis Cord from Seat Assembly BEFORE removing Seat Assembly

8. Push the Seat Assembly forward and out of the Chair.



Slot/Tracks in Mechanism that Plastic Shoe on Chassis fits into



1. Slots with Plastic Tracks will fit over the Plastic Shoes shown on the Chassis during re-assembly



2. Tracks slide onto Shoe during re-assembly



3 Wrap Towels around Back Posts of the Mechanism



4. Carefully tilt Seat Assembly between Arms



5. Tilt Seat Assembly down until the Tracks line up with the Shoes – Long portion of the Shoe should face the rear of the Chair as shown



6. Pull the back of the Seat Frame to slide Tracks onto Shoes until they hit the Rubber Bumpers.



7. Remove the Towels with the seat in the position shown.



8. Start the two Bolts on each side by hand first and then tighten with the Drill.



**For Powered Comfort Recliner:
plug Chassis Cord into Seat
Assembly BEFORE installing the
Back**

9. Line up the Back Posts of the Mechanism with the Back Mounting Brackets.



10. Push the Back upright and press down hard on the top of the Back to set the Spring Clips.



11. Test the Chair by opening and closing it.